



Supply Programs ATD Group
2101-D Cambridge Beltway Drive
Charlotte, NC 28273
Phone: 704-588-9015
Fax: 704-588-1368




Installation Instructions for Matrix-TM on Windows Vista This is for Remote Desktop's Only

1. Make sure you have .net Framework 3.5 installed. If not below is a link for .net Framework 3.5 with Service Pack 1 (*Service Pack 1 is not required but recommended*).

<http://www.microsoft.com/downloads/details.aspx?familyid=ab99342f-5d1a-413d-8319-81da479ab0d7&displaylang=en>


2. Go to Control Panel >User Accounts and disable UAC (User Account Control).
3. Now you are ready to install the Matrix-TM Software.
4. When asked what to install, only check the install manage box.



5. You can rein able the UAC (User Account Control) in User Account after installation if you prefer.



- Once you start the Matrix-TM Manage 4.2 you will need to put in the IP Address for the Matrix Machine that has the database. Once you put in the IP address click **“Apply”** then click the drop down list and select the database and your language and click **“OK”**.



Settings

General

Server IP

User ID

Password

Database Name

Language

Log File

Application TouchForm

Touch Mode

OK Cancel Apply